



**CONDENSING LOW NOX SYSTEM INNOVATION SUPER HIGH EFFICIENCY AUTOMATIC MODULATING COMBINATION BOILER FOR CENTRAL HEATING AND DOMESTIC HOT WATER**

# USER'S GUIDE

## CSI 120(T) Low Nox (with or without built in timer)

It is the law that all gas appliances are installed by a competent person, in accordance with the gas safety installation and use current regulations. To the current Gas Safety (Installation and Use) Regulations B.S.5440:2-(2000).

All CORGI registered installers carry a CORGI ID card and have a registration number. Both should be recorded in your boiler Log book. You can check your installer by calling CORGI direct on 01256 732300.



*The code of practice for the installation, commissioning & servicing of central heating systems*

### ESCAPE OF GAS

**Should a gas leak be suspected, contact your gas supplier without delay.**

**Do NOT search for gas leaks with a naked flame.**

**WARNING:** This appliance must be earthed. Do not touch or tamper with this sealed unit or its components.

### 1. INTRODUCTION

1.1 Please carefully read information given in the booklet to help you again maximum control from your appliance with minimum trouble and cost.

1.1.1 Your Ravenheat Condensing Low Nox Combination Boiler has been designed to supply your Central Heating and Domestic Hot Water directly from one unit. When Central Heating is operating, the circulation will be interrupted when Domestic Hot Water is being drawn off.

This will normally not affect the level of Heating.

#### PLEASE NOTE

Due to the high efficiency and resulting low flue gas exhaust temperature a white plume of condensation vapour (cool steam) will be emitted from the flue outlet terminal, this is quite normal. It will be particularly evident during periods of low outdoor temperature or when the boiler is working at its optimum performance (Plume Management kit is available on request)

### 1.2 CLEARANCES AROUND THE BOILER

- Above 125 mm ( 5 inches)
- Below 150 mm ( 6 inches)
- Front 450 mm (18 inches)
- Sides 5 mm (0.2 inches)
- 25mm (1inch) in front when installed in a cupboard

1.2.1 Minimum clearances are required for safety and maintenance. Do NOT obstruct any purpose made ventilation opening if boiler has been fitted in a compartment.  
Never hang clothes, ect, over the appliance

### 1.3 USER CONTROLS (Fig.1)

1.3.1 This appliance is designed to operate with the minimum of attention by the User. All the controls are to be found on the control pannel.


### 1.4 OPERATING SAFETY CHECKS TO PROTECT YOUR APPLIANCE

1.4.1 Before lighting the Appliance check Central Heating system pressure (Fig.1 item 7) is not less than 1 bar. If it is below this do not light but consult your installer about refilling your system as you may have a leak in the system.

1.4.2 In the event of malfunction of the appliance will be indicate by the relevant error code (Table1) on Digital Display of the control panel (Fig.50). These can be Reset by press a RESET button .  
**If lockout code persist leave the appliance shut down and consult your installer/service engineer immediately.**

Table 1

- 01: Lock out from the Flame Control Unit**
- 02: Flue System obstruction**
- 04: Overheat Lockout**
- 06: Open or short circuit on Sanitary probe**
- 12: Open or short circuit on Heating probe**
- 14: Flame simulation on Flame Control Unit**
- 17: Fault on Fan Control**
- 28: Water Flow Switch Fault or low pressure in the heating system**



**2. OPERATING DOMESTIC HOT WATER**

- 2.1 Select summer / Winter switch on Summer position
- 2.2 Open hot water tap. After about 3 seconds burner will always operate.
- 2.3 Temperature of Domestic Hot Water can be varied by adjusting the water flow rate at the Domestic Hot water. The temperature can be set between minimum ( 40°C) and Maximum (60°C).  
For maximum temperature of Domestic Hot Water leave the control Knob on Maximum position.

**3. OPERATING HEATING AND HOT WATER**

- 3.1 TO SET AND ADJUST BUILT-IN TIMER MODEL SEE OPPOSITE PAGE 3
- 3.2 Select Summer/Winter Switch on Winter position
- 3.3 Switch on timeclock, adjust room stat and/or thermostatic radiator valves to high settings
- 3.4 Burner will operate, temperature output of Central Heating can be adjusted by Central Heating Control Knob(Fig.1). The Knob can be set between minimum(40°C) and Maximum(85°C).While the appliance is being used to provide Domestic Hot water, the Central Heating will not operate.When Domestic Hot Water is not longer required the appliance will automatically revert to Central Heating and should not noticeably affect the level of central heating.  
Adjust external controls required settings.

**NOTE :** An Anti-cycling device is fitted to the Heating Function. When the boiler reaches its set Maximum temperature it will not operate on heating for about 10 minutes , but if the heating temperature return goes 20°C below the set point, the burner will restarts immediately. The domestic Hot Water Function will always operate on demand.

**3.3 TO SHUT DOWN THE APPLIANCE**

- 3.3.1 For short periods, switch Summer/Winter switch to Summer and turn off all hot taps.  
For long periods switch of the on/off switch (Fig.1). If the appliance is to be shut down for long periods when there is a risk of freezing, then appliance should be drained . Similar refilling must be done by a competent person following approved procedure.

**4. CLEANING OF APPLIANCE OUTER CASING**

- 4.1 Use a clean damp cloth. Do not use any abrasive cleaners and with a dry cloth lightly polish to protect painted surfaces.  
Control Panel and fixture can be wiped with damp cloth and dried . Spray polishes must not be used on control panel surfaces or switches.  
Care must be taken in preventing any liquids entering the appliance.

**5. CARE OF YOUR APPLIANCE AND SYSTEM**

- 5.1 Annual servicing of your appliance is required to maintain safety and efficiency of its operation. therefore it is recommended that the appliance is serviced at least once a year and that the whole of the Heating System be checked at the same time by a qualified installer. If it is know or suspected that a fault exists on the boiler then it MUST NOT be used until the fault has been corrected by a COMPETENT PERSON. It is essential that the Instructions in this booklet are strictly followed for safe and economic operation of the boiler.

**SERVICING SHOULD BE CARRIED OUT BY A QUALIFIED INSTALLER**

Ravenheat Manufacturing Ltd  
Chartists Way , Morley , Leeds  
LS 27 9ET





**Chartists Way, Morley, Leeds, LS27 9ET**

**Telephone : 0044(0)113 252 7007**

**Tfax : 0044(0)113 238 0229**

**Website : [www.ravenheat.co.uk](http://www.ravenheat.co.uk) E-mail : [sales@ravenheat.co.uk](mailto:sales@ravenheat.co.uk)**

Ravenheat reserves the right to make changes and improvements in our products which may affect the accuracy of the information contained in this leaflet.